



Guide Claw Installation GRP and TP Series

You Will Need:

Large pipe wrench
Thread locking compound
Hex wrench as indicated below

Guide claw	Pump Type	Set Screw	Hex Wrench size
2" discharge	TP30-49 & GRP16-41	8mm X 1.25	4mm
2 ½" discharge	TP50	8mm X 1.25	4mm
3" discharge	TP53 & TP70	10mm X 1.5	5mm

Inspect threads of discharge and guide claw for excess paint, foreign material or damage; clean threads if necessary.

Apply thread locking compound such as Blue #242 to threaded discharge of pump.

Thread guide claw onto the pump discharge all the way until the flange is snug and the guide ears are in the horizontal position. Pump must sit upright when installed onto base, so claw may need to be unthreaded slightly to achieve proper orientation.

Remove set screw from guide claw, apply thread locking compound to the set screw. Reinstall and tighten set screw. Tighten to 5 ft. lbs. for 8mm screw and 13 ft. lbs. for 10mm screw.

