


PROCEDURE

Using Hopsel, it is easy to extract a representative AutoCAD file of your desired pump and installation arrangement. Simply follow the below steps.

1. Using either the Hydraulic Selection or the Product Selection Browser, select your desired pump model, motor, and installation type (e.g. wet pit installation on autocoupling)
2. Click the **Dimensions** tab on the left side of the screen (**A**) to bring up the drawing preview
3. Locate the **Download** button above the drawing preview (**B**) and click it



4. Save the drawing to your desired location
5. Your file is now available for use in any supported AutoCAD program or viewer